


ZIP

Aluminum Road Wheel & Hub Service Manual

30, 50, & 70



SRAM LLC WARRANTY

EXTENT OF LIMITED WARRANTY

SRAM warrants its products to be free from defects in materials or workmanship for a period of two years after original purchase. This warranty only applies to the original owner and is not transferable. Claims under this warranty must be made through the retailer where the bicycle or the SRAM component was purchased. Original proof of purchase is required.

LOCAL LAW

This warranty statement gives the customer specific legal rights. The customer may also have other rights which vary from state to state (USA), from province to province (Canada), and from country to country elsewhere in the world.

To the extent that this warranty statement is inconsistent with the local law, this warranty shall be deemed modified to be consistent with such law, under such local law, certain disclaimers and limitations of this warranty statement may apply to the customer. For example, some states in the United States of America, as well as some governments outside of the United States (including provinces in Canada) may:

- Preclude the disclaimers and limitations of this warranty statement from limiting the statutory rights of the consumer (e.g. United Kingdom).
- Otherwise restrict the ability of a manufacturer to enforce such disclaimers or limitations.

LIMITATIONS OF LIABILITY

To the extent allowed by local law, except for the obligations specifically set forth in this warranty statement, in no event shall SRAM or its third party suppliers be liable for direct, indirect, special, incidental, or consequential damages.

LIMITATIONS OF WARRANTY

This warranty does not apply to products that have been incorrectly installed and/or adjusted according to the respective SRAM technical installation manual. The SRAM installation manuals can be found online at www.sram.com, www.rockshox.com, www.avidbike.com, www.truvativ.com, or www.zipp.com.

This warranty does not apply to damage to the product caused by a crash, impact, abuse of the product, non-compliance with manufacturers specifications of usage or any other circumstances in which the product has been subjected to forces or loads beyond its design.

This warranty does not apply when the product has been modified.

This warranty does not apply when the serial number or production code has been deliberately altered, defaced or removed.

This warranty does not apply to normal wear and tear. Wear and tear parts are subject to damage as a result of normal use, failure to service according to SRAM recommendations and/or riding or installation in conditions or applications other than recommended.

Wear and tear parts are identified as:

- | | | |
|---|----------------------------|----------------------|
| • Dust seals | • Brake sleeves | • Bottomout pads |
| • Bushings | • Brake pads | • Bearings |
| • Air sealing o-rings | • Chains | • Bearing races |
| • Glide rings | • Sprockets | • Pawls |
| • Rubber moving parts | • Cassettes | • Transmission gears |
| • Foam rings | • Shifter and brake cables | • Spokes |
| • Rear shock mounting hardware and main seals | (inner and outer) | • Free hubs |
| • Upper tubes (stanchions) | • Handlebar grips | • Aero bar pads |
| • Stripped threads/bolts | • Shifter grips | • Corrosion |
| (aluminium, titanium, magnesium or steel) | • Jockey wheels | • Tools |
| | • Disc brake rotors | |
| | • Wheel braking surfaces | |

This warranty shall not cover damages caused by the use of parts of different manufacturers.

This warranty shall not cover damages caused by the use of parts that are not compatible, suitable and/or authorised by SRAM for use with SRAM components.

This warranty shall not cover damages resulting from commercial (rental) use.

All SRAM wheels (carbon and AL) have a 100 kg (220 lbs) rider weight limit.

© Copyright SRAM LLC 2010

This document includes trademarks and registered trademarks of SRAM LLC designated by the symbols ™ and ® respectively.

For exploded diagram and part number information, please refer to the Spare Parts Catalog available on our website at www.sram.com.

For order information, please contact your local SRAM distributor or dealer.

Information contained in this document is subject to change at any time without prior notice.

Your product's appearance may differ from the pictures/diagrams contained in this document.

Product names used in this document may be trademarks or registered trademarks of others.

TABLE OF CONTENTS

SRAM S30 AL GOLD/RACE/SPRINT & S27 AL COMP HUB.....	5
TECHNICAL DATA	5
REAR HUB SERVICE	6
TOOLS NEEDED FOR SERVICE.....	6
REPLACEMENT PARTS	6
DISASSEMBLY	7
ASSEMBLY	9
HUB ADJUSTMENT & VERIFICATION - REAR HUB.....	12
FRONT HUB SERVICE	14
TOOLS NEEDED FOR SERVICE.....	14
REPLACEMENT PARTS	14
DISASSEMBLY	15
ASSEMBLY	16
HUB ADJUSTMENT & VERIFICATION - FRONT HUB.....	17
WHEEL BUILD & SPOKE REPLACEMENT.....	19
REPLACEMENT PARTS	19
SRAM S30 AL GOLD, AL RACE, & AL SPRINT	19
SRAM S27 AL COMP	19
REAR WHEEL LACING	20
FRONT WHEEL LACING	21



SAFETY FIRST!

We care about YOU. Please, always wear your safety glasses and protective gloves when servicing your wheels.

Protect yourself! Wear your safety gear!

HOW TO USE THIS SERVICE GUIDE

*This service guide is sub-divided into five independent service sections: **Rear Hub Service, Hub Adjustment & Verification - Rear Hub, Front Hub Service, Hub Adjustment & Verification - Front Hub, and Wheel Lacing & Spoke Replacement.***

*While the **Rear Hub, Front Hub, and Wheel Lacing** sections can be completed independently or in tandem, it is mandatory that you perform the steps detailed in the **Hub Adjustment & Verification** sections for rear and front hubs upon completion of any service. **Improper preload adjustment caused by over-tightening the hub end caps will permanently damage the hub bearing once ridden and will void the warranty.***

You can service your hub while the hub is still in the wheel. However, if your spokes or rim are damaged, you can remove the hub from the wheel which will make servicing your hub easier. Use a spoke wrench to detension the spokes, then use a pair of metal snips to cut the spokes, remove the hub from the wheel, and remove the spoke ends from the hub (not pictured).

REAR HUB SERVICE

TOOLS NEEDED FOR SERVICE

Safety glasses

Gloves

(2) 5 mm hex wrenches

Drift tool

Rubber or plastic mallet

Grease

Grease brush

SRAM bearing installation tools (see diagram)



SRAM Bearing Installation Tools

REPLACEMENT PARTS

Hub bearings

Driver body


Driver body pawls

Driver body leaf springs

Driver body seal

For part numbers, please refer to the SRAM Wheels Spare Parts List in the Service section of www.sram.com

Rear hub



DISASSEMBLY

1



- 2 Insert a 5 mm hex wrench into both end caps. Hold the drive side wrench in place and turn the non-drive side end cap counter-clockwise to remove it.




- 3 Remove the cassette body assembly, by hand, from the hub shell.




- 4 Remove the axle, by hand, from the driver body.

IMPORTANT:

There is a flat washer that rests on the bearing located on the side of the driver body with the pawls and leaf springs. If this washer falls off when you remove the axle, set it aside until you are ready for assembly.



- 5** Use a drift type tool and a rubber or plastic mallet to firmly tap out the drive side bearing. Repeat this process to remove the non-drive side bearing.




Remove spacer


- 6** Use your fingers to remove the flat washer from the driver body.



- 7** Use your fingers or a pick to carefully remove the pawls and leaf springs. Inspect the pawls and leaf springs for signs of damage or wear. If any of the pawls or leaf springs exhibit signs of wear or damage, replace all of them. Otherwise, remove any grease on the pawls and leaf springs with a clean rag.




- 8** Use your fingers to remove the external lip seal. Inspect the external lip seal for signs of damage or wear. If there are any signs of damage or wear, replace it. Otherwise, remove any grease on the external lip seal with a clean rag.



ASSEMBLY


- 1** Press the external lip seal, with the smooth side facing the driver body, over the leaf spring and pawl carrier.



IMPORTANT:

The external lip seal must be fully seated against the thin shoulder of the driver body.


- 2** Insert the leaf springs into the spring slots. Orient the long edge of each spring along the inside of the carrier so that it points clockwise.




- 3** Insert the pawls into the pawl slots. You may need to use a pick to compress each leaf spring to assist with inserting the pawls. Orient the cambered edge (the edge that is slightly more curved) of each pawl along the outside of the carrier so that it points counter-clockwise.



4 Apply a light coat of grease to the leaf springs and pawls.



5 Insert the axle through the driver body.



6 Slide the flat washer over the axle until it rests on the leaf spring and pawl carrier.



TIPS & TRICKS

If you have a bearing press, you can simultaneously install both hub shell bearings by using the two Bearing Installation Tools. Insert a new bearing into each end of the hub shell. Place the large end of each Bearing Installation Tool against each of the bearings. Use the bearing press to carefully seat both bearings against the shoulders inside the hub (not pictured).

If you are installing the hub bearings one at a time, place a clean rag between the hub shell and the work bench. This will protect the finish of the hub shell from damage during the bearing installation process.

- 7** Place the hub shell, drive side down, on a stable flat surface. Insert a new bearing into the non-drive side hub shell. Place the large end of the Bearing Installation Tool against the bearing. Use a rubber or plastic mallet to gently but firmly tap the bearing into place until it is seated against the shoulder inside the hub shell.

IMPORTANT:

Install the non-drive side bearing first.




- 8** Turn the hub shell over so that the non-drive side is down. Insert **a new spacer, followed by a new bearing**, into the drive side hub shell. Place the large end of the Bearing Installation Tool against the bearing. Use a rubber or plastic mallet to gently but firmly tap the bearing into place until the spacer is seated against the shoulder inside the hub shell.

IMPORTANT:


The Bearing Installation Tool must contact both the inner and outer races.



- 9** Evenly apply a small amount of grease (approximately 1 gram or an amount roughly the size of a pea) to the driver body ratchet ring.



- 10** Insert the cassette body assembly through the drive-side of the hub shell. Use your fingers to compress the pawls in order to fully seat and engage the pawls with the driver body ratchet ring.




11 Insert a 5 mm hex wrench into the drive side end cap. Hold the wrench in place and gently thread the non-drive side end cap, by hand, onto the axle until it bottoms out and stops turning.

IMPORTANT:

To complete your hub service, move onto the ***Wheel Lacing & Spoke Replacement*** section (if necessary) then complete the ***mandatory Hub Adjustment and Verification - Rear Hub*** section.

TIGHTEN WITH TOOLS. (what does this mean?)



THIS COMPLETES THE REAR HUB SERVICE

FRONT HUB SERVICE

TOOLS NEEDED FOR SERVICE

Safety glasses

Gloves

(2) 5 mm hex wrenches

Drift tool

Rubber or plastic mallet

Grease

Grease brush

SRAM bearing installation tools (see diagram)




SRAM Bearing Installation Tools

REPLACEMENT PARTS

Hub bearings

For part numbers, please refer to the SRAM Wheels Spare Parts List in the Service section of www.sram.com

Front Hub



DISASSEMBLY

- 1** Use a 2 mm hex wrench to loosen, but not remove, the set screw located on the non-drive side end cap.




- 2** Insert a 5 mm hex wrench into both end caps. Hold the drive side wrench in place and turn the non-drive side end cap counter-clockwise to remove it.



- 3** Remove the axle, by hand, from the hub shell.



- 4** Use a drift type tool and a rubber or plastic mallet to firmly tap out one of the bearings. **Remove the spacer.** Turn the hub shell over and repeat this process to remove the other bearing.




ASSEMBLY

TIPS & TRICKS

If you have a bearing press, you can simultaneously install both hub shell bearings by using the two Bearing Installation Tools. Insert a new bearing into each end of the hub shell. Place the large end of each Bearing Installation Tool against each of the bearings. Use the bearing press to carefully seat both bearings against the shoulders inside the hub (not pictured).

If you are installing the hub bearings one at a time, place a clean rag between the hub shell and the work bench. This will protect the finish of the hub shell from damage during the bearing installation process.

- 1** Place the hub shell on a stable flat surface. **Insert a new spacer, followed by a new bearing** into one side of the hub shell. Place the small end of the Bearing Installation Tool against the bearing. Use a rubber or plastic mallet to gently but firmly tap the bearing into place until **the spacer** is seated against the shoulder inside the hub shell. Turn the hub shell over and repeat this process to install the other new bearing.



- 2** Insert the axle through the hub shell assembly.



- 3** Insert a 5 mm hex wrench into the drive side end cap. Hold the wrench in place and gently thread the non-drive side end cap, by hand, onto the axle until it bottoms out and stops turning.

IMPORTANT:

To complete your hub service, move onto the ***Wheel Lacing & Spoke Replacement*** section (if necessary) then complete the ***mandatory Hub Adjustment and Verification - Front Hub*** section.

TIGHTEN COMPLETELY



WHEEL BUILD & SPOKE REPLACEMENT

This portion of the service guide covers general wheel build and spoke replacement. As there are many different methods for spoke tensioning, the following information provides the final spoke tension you should achieve using your preferred method for spoke tensioning.

TOOLS NEEDED FOR SERVICE

Safety glasses

Loctite® 577

Bladed spoke adjustment tool (ex. Park Tool® BSH-4)

Spoke wrench: Park Tool® SW-15 for internal spoke nipples


Spoke wrench for 0.127" (3.23 mm) external spoke nipples

Tensiometer with tension conversion chart

Truing stand

WHEEL BUILD TIPS

- Lightly coat the threads of the replacement spokes with Loctite® 577.
- During the wheel build process, pre-stress the wheel by lightly squeezing pairs of spokes to ensure the spokes seat properly in both the hub and the rim.
- ZIPP wheels use both radial and 1 cross spoke lacing patterns. For 1 cross lacing patterns, the spokes that point rearward should be installed **on the bottom** so they sit against the hub shell. The spokes that point forward should be install **on the top**.



1 cross lacing pattern

REPLACEMENT PARTS

For part numbers, please refer to the SRAM Wheels Spare Parts List in the Service section of www.sram.com.

ZIPP 30

Use Sapim CX-Ray replacement spokes


		Spoke Count	Spoke Length	Lacing Pattern	Final Spoke Tension
Front Wheel	Drive side	9	282 mm	Radial	105 ± 10 kgf (1030 N ± 98 N)
	Non-drive side	9			
Rear Wheel	Drive side	10	272 mm	Radial	AL Gold: 150 ± 15 kgf (1471 N ± 147 N) AL Race: 150 ± 15 kgf (1471 N ± 147 N) AL Sprint: 130 ± 15 kgf (1275 N ± 147 N)
	Non-drive side	10	286 mm	1 cross	AL Gold: 85 ± 15 kgf (833 N ± 147 N) AL Race: 85 ± 15 kgf (833 N ± 147 N) AL Sprint: 65 ± 15 kgf (637 N ± 147 N)

REAR WHEEL LACING


1. Start on the drive side of the wheel. Orient the wheel so that the serial number on the rim is facing down and the cassette driver body of the rear hub is facing up.
2. Insert the threaded end of spoke ① into the first hole *to the left* of the rim valve hole. Carefully thread a spoke nipple onto the spoke, 1/2 turn. Install the head of spoke ① into one of the spoke slots of the drive side hub flange.
3. Repeat this procedure for the remaining 9 drive side spokes, following the illustrated drive side lacing pattern.
4. Carefully turn the wheel over so that the cassette driver body is facing down.
5. Insert the threaded end of spoke ⑪ into the second hole *to the right* of the rim valve hole. Carefully thread a spoke nipple onto the spoke, 1/2 turn. Install spoke ⑪ into the hub flange spoke slot closest to the 3 o'clock position that angles toward the valve hole
6. Insert the threaded end of spoke ⑫ into the fourth hole *to the right* of the rim valve hole. Carefully thread a spoke nipple onto the spoke, 1/2 turn. Install spoke ⑫ into the hub flange spoke slot closest to the 12 o'clock position that angles to the right.
7. Repeat this procedure for the remaining 8 non-drive side spokes. Refer to the spoke lacing diagram for the proper spoke installation pattern.
8. Use a spoke wrench to turn each of the the drive side spokes in 1/2 turn increments until the drive side spoke tension is at approximately 30-40% of the final value: **45-60 kgf (441-588 N)**
9. Install the wheel into a truing stand and check for roundness. Tighten or loosen the drive side spokes until the wheel is round.
10. Install the wheel into a truing stand. Use a spoke wrench to turn each of the spokes in 1/2 turn increments to increase non-drive side spoke tension. Continually check for roundness (vertical movement) and trueness (side-to-side movement).

WHEEL BUILD TIPS


- Control wheel roundness by tightening/loosening the drive side spokes.
 - Control wheel trueness by tightening/loosening the non-drive side spokes.
 - Use a bladed spoke adjustment tool to prevent the spokes from twisting during adjustment.
11. Continue tightening both drive side and non-drive side spokes in 1/8 - 1/4 turn increments until the final tension has been achieved. Refer to the spoke chart for recommended final tension measurements.



drive side lacing pattern




non-drive side lacing pattern




non-drive side spoke lacing diagram

FRONT WHEEL LACING

1. Orient the wheel so that the serial number on the rim is facing up, and the hub decal is facing up.
2. Insert the threaded end of spoke ① into the first hole *to the left* of the rim valve hole. Carefully thread a spoke nipple onto the spoke, 1/2 turn. Install spoke ① into one of the spoke slots of the hub flange.
3. Repeat this procedure for the remaining 8 spokes on this side of the wheel, following the illustrated lacing pattern.
4. Carefully turn the wheel over.
5. Insert the threaded end of spoke ⑩ into the first hole *to the left* of the rim valve hole. Carefully thread a spoke nipple onto the spoke, 1/2 turn. Install spoke ⑩ into the hub flange spoke slot closest to the 12 o'clock position.
6. Repeat this procedure for the remaining 9 spokes. Refer to the spoke lacing diagram for the proper spoke installation pattern.
7. Install the wheel into a truing stand. Use a spoke wrench to turn each of the spokes in 1/2 turn increments to increase spoke tension. Continually check for roundness (vertical movement) and trueness (side-to-side movement).
8. Continue tightening both drive side and non-drive side spokes in 1/8 - 1/4 turn increments until the final tension has been achieved. Refer to the spoke chart for recommended final tension measurements.



radial lacing pattern



[www.sram.com]