## SRAM RED® eTap® 11 Speed Component Compatibility



MASTER COMPONENT



11 SPEED ROAD REAR DERAILLEUR

RD-RED-E-A1

RD-RED-E-A2

SYSTEM COMPONENT



11 SPEED ROAD FRONT DERAILLEUR

FD-RED-E-A1

SYSTEM CONTROLLERS

## DROP HANDLEBAR<sup>1</sup>





LEFT CONTROLLER	RIGHT CONTROLLER

DISC	SB-RED-EHRD-A1	SB-RED-EHRD-A1
	ED-RED-D1	ED-RED-D1
	ED-FRC-D1	ED-FRC-D1
RIM	EB-RED-A1	EB-RED-A1
	EB-RED-D1	EB-RED-D1
	EB-FRC-D1	EB-FRC-D1

## AERO HANDLEBAR<sup>2</sup>




BLIPBOX™

ES-EAC-BBOX-A1

ES-EAC-BBOX-D1

## SHIFT BUTTONS

CHOOSE YOUR ACCESSORY SHIFT BUTTONS TO WORK WITH YOUR CONTROLS.



**Red Shaded Model Codes**: AXS® Controllers that can be used as a replacement controller with a SRAM RED eTap 11 Speed front and rear derailleur when firmware, 2.29.4 or later, is installed. Use the SRAM AXS App to update firmware to 2.29.4 or later on the AXS Controllers, then pair the system. Consult the SRAM RED eTap Systems user manual at www.sram.com/service for System Pairing.

Note: The SRAM RED eTap 11 Speed front and rear derailleur will not be visible in the SRAM AXS App, require a firmware update, or have the full AXS system configuration benefits



<sup>&</sup>lt;sup>1</sup> Accessory shift buttons are optional for drop handlebar controls.

<sup>&</sup>lt;sup>2</sup> One pair of shift buttons must be used with the BlipBox.